

Mercedes_W907_half_Fis

Table of contents

Getting Started	3
System requirements	3
Getting help	3

Getting Started

System requirements

Mercedes W907 1/2Fis



Required:
UHDS Tool
Activation MS0015
Jtag Tool

Getting help

For change Millage we have to do first Step:

1. Connect Jtag as on picture and press prepare Flash
After soft finish disconnect Dash and put back into car
2. Now we can Write KM

For Read/Write EEPROM we don't need prepare Flash

W907 R7F701414

