Peugeot_308_Dash_CMB_T 9EVP

Table of contents

Getting Started

System requirements

1. UHDS Tool
2. PT0020 Activation
3. Bench cable

Getting help

Programming by dash connector.
Bench Connection:

16 OBD (+12V)

4, 5 (GND)

7 Kline

6 CAN H

14 CAN L