

GM_BCM_R7F7015873

Table of contents

Getting Started	3
System requirements	3
Getting help	3

Getting Started

System requirements

Required:
UHDS Interface
Jtag Interface
Sonde RH v1

JG0050 activation
OL0019 Activation

Getting help

Available options:
-Set New KM
-Make virgin modue - give possibilty prepare module for learn it as new module

