

PSA_CMB_P2_Visteon

Table of contents

Getting Started	3
System requirements	3
Getting help	3

Getting Started

System requirements

- 1.UHDS Interface
- 2.PT0021 Activation
- 3.Cable bench connection

Getting help

Possible options:

- 1.Read Km
- 2.Write KM
- 3.Read EEprom
- 4.Write EEprom

