

Toyota_Airbag_R7F701A2 23

Table of contents

Getting Started	3
System requirements	3
Getting help	3

Getting Started

System requirements

1. UHDS interface not important serial number (old or new)
2. AB0055 activation
3. Jtag interface with JG0025 activation or other RH850 programmer * - only if flash file is not currently present in our database

Getting help

Can clear crash OBD or by Airbag connector.

Module will be flashed from database file.

If file is not available you have to open module use TH850 programmer and read Flash file (not dataflash !!!)

After that you can close ECU and connect by CAN or put to car and do it .